

Swaging mandrels for 4200-serie fittings



Product info
Product group

To control that the swaging has resulted in
900

To control that the swaging has resulted in the right internal collapse. GO-side should pass through the fitting to make sure that the swaging is not overdone. The STOP-side should stop in the middle of the tail to ensure that the swaging is sufficient.

Dimension (Inch)

90150024

1 1/2"

90150305

3/16"

