## Swaging mandrels for 4400-serie fittings



Product info Product group

To control that the swaging has resulted in

The STOP-side should stop in the middle of the tail to ensure that the swaging is sufficient.

|          | Dimension (Inch) |
|----------|------------------|
| 90130004 | 1/4"             |
| 90130006 | 3/8"             |
| 90130008 | 1/2"             |
| 90130010 | 5/8"             |
| 90130012 | 3/4"             |
| 90130016 | 1"               |
| 90130020 | 1 1/4"           |
| 90130024 | 1 1/2"           |
| 90130032 | 2"               |

